

PRODUCT CHANGE NOTIFICATION (PCN)



PCN Number: 06/2024
Title: **boost V Trigger Mode standardization**
Product Family: boost V
Release date: July, 2024
Contact: Basler Support
Type of Change: Firmware naming & parameter setting
Product design

Reason for Change

Change of Trigger naming and parameter settings to enhance ease of use throughout Basler boost families.

Change Description

To enhance the overall product experience with our boost families (boost R /boost V) we have harmonized the overall naming and parameter settings of the following trigger functionalities.

Trigger description OLD	Trigger description NEW
<u>Scenario 1:</u> TriggerMode= On TriggerMode= TriggerWidth TriggerSelector= ExposureStart TriggerSource= CXPTTrigger0 TriggerActivation= RisingEdge/ FallingEdge	<u>Scenario 1:</u> TriggerMode= On TriggerMode= TriggerControlled TriggerSelector= ExposureStart/ ExposureEnd TriggerSource= CXPTTrigger0/ CXPTTrigger1

Basler AG
Europe, Middle East, Africa
Tel. +49 4102 463 515
Fax +49 4102 463 599
support.europe@baslerweb.com
www.baslerweb.com

The Americas
Tel. +1 610 280 0171
Fax +1 610 280 7608
support.usa@baslerweb.com

Asia-Pacific Region
Tel. +65 6367 1355
Fax +65 6367 1255
support.asia@baslerweb.com

PRODUCT CHANGE NOTIFICATION (PCN)

Trigger description OLD	Trigger description NEW
<p><u>Scenario 2:</u> TriggerMode= On TriggerMode= Timed TriggerSelector= ExposureStart TriggerSource= CXPTrigger0 TriggerActivation= RisingEdge/ FallingEdge</p>	<p><u>Scenario 2:</u> TriggerMode= On TriggerMode= Timed TriggerSelector= ExposureStart TriggerSource= CXPTrigger0/ CXPTrigger1</p>

With this change the user experience throughout the product families will be equal. This change might need some changes in your current design, when it comes to naming and settings. It does not have an effect on overall product performance. In case of any questions or if you need additional support please contact our Basler support team via support.central@baslerweb.com.

Basler AG
Europe, Middle East, Africa
Tel. +49 4102 463 515
Fax +49 4102 463 599
support.europe@baslerweb.com
www.baslerweb.com

The Americas
Tel. +1 610 280 0171
Fax +1 610 280 7608
support.usa@baslerweb.com

Asia-Pacific Region
Tel. +65 6367 1355
Fax +65 6367 1255
support.asia@baslerweb.com

Affected models and expected first production / shipping date

Model	Part Number	Revision	Production Date
boA5120-150cm/cc	2200001210 2200001211	03 and higher	07/2024
boA5120-230cm/cc	2200001214 2200001215	01 and higher	07/2024
boA9344-70cm/cc	2200001212 2200001213	03 and higher	07/2024
boA9344-30cm/cc	2200002031 2200002032	03 and higher	07/2024

Additional Information

Basler may make changes to specifications and product descriptions at any time, without notice. The information in this document is subject to change without notice.

There is no claim to exchange or update the stock or the delivered goods due to the PCN. This applies to customer inventories as well as Basler's own inventory. Also there is no claim to receive the old revision after change.

Basler AG
Europe, Middle East, Africa
Tel. +49 4102 463 515
Fax +49 4102 463 599
support.europe@baslerweb.com
www.baslerweb.com

The Americas
Tel. +1 610 280 0171
Fax +1 610 280 7608
support.usa@baslerweb.com

Asia-Pacific Region
Tel. +65 6367 1355
Fax +65 6367 1255
support.asia@baslerweb.com